



High Resolution Touch Screen



Owner's Manual and Installation Instructions



IMPORTANT

Follow the Installation Instructions before proceeding. Set the thermostat mode to “OFF” prior to changing settings in setup or restoring factory defaults.

North American Emissions Compliance

United States

Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Canada

Industry Canada Statement

The term IC before the certification/registration number only signifies that the Industry Canada technical specifications were met.

Le terme “IC” précédant le numéro d'accréditation/inscription signifie simplement que le produit est conforme aux spécifications techniques d'Industry Canada.

This color touch screen has the ability to receive updates to its firmware. Periodically firmware updates are released by the manufacturer to add features and/or performance enhancements. This manual was produced reflecting the most current firmware/feature set at the time of publication, firmware rev. 5.10. Firmware releases after rev. 5.10 may not be adequately depicted in this manual. Please refer to the appropriate website or contact your place of purchase to learn about changes to the thermostat after firmware release 5.10.



Auto-Changeover: A mode in which the thermostat will turn on the heating or cooling based on room temperature demand.

Cool Setpoint: The warmest temperature that the space should rise to before cooling is turned on (without regard to deadband).

Deadband: The number of degrees the thermostat will wait, once a setpoint has been reached, before energizing heating or cooling.

Differential: The forced temperature difference between the *heat setpoint* and the *cool setpoint*.

Heat Setpoint: The coolest temperature that the space should drop to before heating is turned on (without regard to deadband).

Icon: The word or symbol that appears on the thermostat display.

Mode: The current operating condition of the thermostat (i.e. Off, Heat, Cool, Auto, Program On).

Non-Programmable Thermostat: A thermostat that does not have the capability of running *Time Period Programming*.

Programmable Thermostat: A thermostat that has the capability of running *Time Period Programming*.

Temperature Swing: *Same as Deadband.*

Time Period Programming: A program that allows the thermostat to automatically adjust the *heat setpoint* and/or the *cool setpoint* based on the time of the day. *Same as Schedule.*

Table of Contents

GET TO KNOW YOUR THERMOSTAT

Home Screen	1
Menu Screens.....	1
Dropdown Dashboard	2
Care and use of your thermostat.....	5

QUICK START

Selecting your desired temperature and mode	6
Using the Fan button	6
Using the Override button.....	7
Setting the time	9
Setting the date.....	10
Daylight Savings setup.....	10
Connect to Wi-Fi.....	11
WiFi Setup.....	12

MAIN MENU BUTTONS

View My Schedule	15
Edit My Schedule.....	15
Unoccupied Settings	16

FAN SETTINGS	17
Fan On/Auto.....	18
Occupied Fan State	18
Preoccupancy Fan Purge	18
Preoccupancy Fan Purge Time.....	18

SCREENSAVER	19
Screensaver On/Off.....	20
Screensaver Setup	20
Screensaver Preview	20

ALERTS.....	21
View Current Alerts.....	22
Reset Alerts.....	22
Set/Edit Reminders	22
Service Information (Who To Call For Service).....	22

Table of Contents

DISPLAY	23
Active Brightness.....	24
Idle Brightness	24
Night Dimmer	24
Maintenance	25
PREFERENCES.....	26
User Interface Themes.....	27
Custom Wallpaper.....	27
Heat/Cool Indicator.....	27
Sound Options.....	27
HUMIDITY	28
Humidification Settings.....	29
Dehumidification Settings.....	29
HOLIDAYS.....	30
Holiday Schedule On/Off.....	31
Edit Holidays	31
Preset Holidays.....	33
SECURITY	34
Auto Screenlock.....	35
Setpoint Limits.....	35
Maximum Override Time.....	35
INFORMATION	36
View Runtime Graphs.....	37
Who To Call For Service.....	37
SETTINGS.....	38
Thermostat Name	42
Available Modes.....	42
SD Card (Import and Export).....	42

Table of Contents

General Setup	42
Units (F or C)	42
Language	43
Smart Recovery On/Off	43
Installation Settings	43
Heat & Cool Stages	43
Heat & Cool Stages	43
Compressor Stages	43
Aux Heat Stages	43
Timers & Deadbands	43
Automated Demand Response	45
Heat Pump Settings	59
Heat Pump Lockout - Enabled/Disabled	59
Heat Pump Lockout Outdoor Temp	59
Aux Heat Lockout Enabled/Disabled	59
Aux Heat Lockout Temp	59
Aux Output Settings	60
Fan Off Delay	61
Sensor Settings	61
Control Sensor	61
Wired Sensor Use	61
Calibrate Sensors	62
Test Outputs	62
Dealer Information	63
Upgrade Firmware	63
Delete Custom Images	63
Calibrate Clock	63
Reset to Factory Default Settings	63
Restart Thermostat	63

Table of Contents



WI-FI	65
Status.....	65
Setup.....	65
Local API Option	65
SKYPORT.....	69
Account	69
EMERGENCY HEAT	70
COLORDISPLAY DESKTOP APP	71
Installing the ColorDisplay Desktop App	71
Uploading Photos.....	72
INSTALLATION INSTRUCTIONS.....	73
Remove & Replace the Old Thermostat	73
Wire Connections	74
Determining Your Existing Wiring and Equipment.....	75
Making 4 Wires Work When 5 Wires Are Required.....	77
Making 5 Wires Work When 6 Wires Are Required.....	78
The T9100 Thermostat Backplate.....	79
Explanation Of the Thermostat Dip Switches	80
Sample Wiring Diagrams	81
TROUBLESHOOTING	85
INDEX.....	86
WARRANTY	91
TECHNICAL SPECIFICATIONS.....	92


Get To Know Your Thermostat




Home Screen

Backlit Color Touch Screen Display


Connectivity Symbol Table	
	Not connected to Wi-Fi
	Connected to local access point w/IP address without Skyport access
	Connected to local access point w/IP address, but not yet connected to Skyport
	Connected to Skyport



Main Menu Screen



Sub Menu Screen



Get To Know Your Thermostat



Dropdown Dashboard

The Dropdown Dashboard displays temperature, humidity, and other readings. It will also show the high and low readings of the day.




Connectivity Symbol Table

	Not connected to Wi-Fi
	Connected to local access point w/IP address without Skyport enabled
	Connected to local access point w/IP address, but not yet connected to Skyport
	Connected to Skyport

Dropdown Dashboard

(The contents of your Dashboard may vary)



Heating and Cooling amounts for the day

press for more info

Get To Know Your Thermostat



Dropdown Dashboard


(The contents of your Dashboard may vary)



Weather Display with forecast for the following 3 days

(Skyport connection required for weather)

Weather Display



Thermostats Onboard


This page displays sensor information. Select 'Onboard' to view room temperature, and if equipped, humidity sensors that are built-into the thermostat. Select 'Wireless' to view all wireless sensors that this thermostat has access to.

Get To Know Your Thermostat



These 3 screens are for informational purposes only. Settings may not be changed from these screens.

Thermostat Info



Equipment Configuration



Thermostat Outputs

Care and Use of Your Thermostat

Pencils, pens and other sharp objects should never be used on your thermostat; these may damage your touch screen.

Only use your finger tip to press the screen buttons.



Use a soft, damp cloth to clean the screen.

CAUTION

DO NOT USE ABRASIVE CLEANERS OR CLEANERS THAT CONTAIN SOLVENTS. DO NOT SPRAY ANYTHING DIRECTLY ONTO THE THERMOSTAT.


ATTENTION

NE PAS UTILISER UN NETTOYANT ABRASIF OU UN NETTOYANT QUI CONTIENT DES SOLVANTS. NE PAS VAPORISER DIRECTEMENT SUR LE THERMOSTAT.

Selecting Your Desired Temperature and Mode

Press **WARMER** or **COOLER** to adjust temperature

The Heat or Cool Setpoint is the temperature the room has to reach before heating or cooling will turn off.



Press **MODE** or the **MODE Icon**



HEAT will allow only operation of the heating system.


COOL will allow only operation of the cooling system.

AUTO will allow operation of the heating and cooling systems.

OFF - heating and cooling systems are turned off.

AUTO-CHANGEOVER MODE - Pressing the WARMER or COOLER buttons in Auto mode will adjust both the heat and cool setpoints simultaneously. To adjust heat and cool setpoints individually, choose HEAT mode to adjust the heat setpoint and COOL mode to adjust the cool setpoint, then return to AUTO mode.

HEAT OR COOL MODE - Pressing the WARMER or COOLER buttons in Heat or Cool mode will adjust only the heat or cool setpoints.



Using the Fan Button

Press **FAN Icon**



FAN ON fan runs constantly except in OFF Mode.

FAN AUTO fan only runs with a heating or cooling demand.

Note: FAN button is disabled during Program Run Mode.



Using the Override Button

OVERRIDE

NOTE: Override may only be used when the thermostat is set to Program RUN or Holiday ON modes.



Override


Unoccupied Operation - During programmed, unoccupied periods, pressing the **OVERRIDE** button will force the thermostat into Occupied 1 settings. When the **OVERRIDE** button is pressed, a timer screen will appear and allow the user to choose from 30 minutes to up to 4 hours of override time. To turn off the override timer, press the **OVERRIDE** button and when the timer screen appears, press **CANCEL OVERRIDE**.

Occupied Operation - During programmed, occupied periods, pressing the **OVERRIDE** button will force the thermostat into an unoccupied period for the rest of the day. During this forced unoccupied period, the **OVERRIDE** button will operate as described above.

Holiday Operation - During Holiday Mode, pressing the **OVERRIDE** button will force the thermostat into Occupied 1 settings. When the **OVERRIDE** button is pressed, a timer screen will appear and allow the user to choose from 30 minutes to up to 4 hours of override time. To turn off the override timer, press the **OVERRIDE** button and when the timer screen appears, press **CANCEL OVERRIDE**.

Quick Start – Set Time & Date

NOTE: When the thermostat is connected to the Skyport; the Time & Date are automatically synchronized to the Skyport Cloud, including automatic Daylight Savings adjustments. Your time zone is selected in the Skyport web application.



Setting the Time

Press **MENU** then 

Press 
Set Time & Date

Press  **Set Current Time** (12:00 AM)

Press  **and**  **to set the current time.**
 

Press  **when finished.**

Choose

 **• Use AM/PM - ON**

For 12 hour AM/PM clock

 **• Use AM/PM - OFF**

For 24 hour clock

Press  **when finished.**

Setting the Date

Press **Set Current Date** 6/1/2013

Press or to set the current month and year.

Press the day on the calendar

Su	Mo	Tu	We	Th	Fr	Sa
27	28	29	30	1	2	3
4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	31
1	2	3	4	5	6	7

Press **Press** **BACK** when finished.

• Daylight Savings Setup

Turn Daylight Savings Time on or off.

• Daylight Savings Time - OFF

• Daylight Savings Time - ON

Adjust when Daylight Savings Time begins.

• Start Schedule

Adjust when Daylight Savings Time ends.

• Starts On (2nd)

• Day (Sun)

• Month (March)

Press **BACK**

after making a change to a selection.

• Stop Schedule

• Ends On (1st)

• Day (Sun)


• Month (November)

Press **BACK**

or the Home button when finished.

Connect to Wi-Fi (from initial start up)

When power is connected to the thermostat and it has not been configured to connect to a Wi-Fi Access point, the following message appears:



YES



Press YES

Select the access point you wish to connect to from the list.



Enter the password for the Wi-Fi Access Point and press **NEXT**.



Select automatic setup and press **NEXT**.



When finished, a dialog box will appear confirming the successful connection to the local Wi-Fi Access Point.





Select **OK**, then the Wi-Fi status page will appear. Upon closing of the Wi-Fi status page, you will be asked to join the thermostat to a Skyport account.



Select **YES** and follow the onscreen instructions to create a new Skyport account or to add the thermostat to an existing account.

Quick Start – Connect to Wi-Fi (from menus)



Select the access point from the list that you want to connect to.



Enter the password for the Wi-Fi Access Point and press **NEXT**.



Select automatic setup and press **NEXT**.



When finished, a dialog box will appear confirming the successful connection to the local Wi-Fi Access Point.



Select **OK**, then the Wi-Fi status page will appear. Upon closing of the Wi-Fi status page, you will be asked to join the thermostat to a Skyport account.



Select **YES** and follow the onscreen instructions to create a new Skyport account or to add the thermostat to an existing account.

Quick Start – Connect to Wi-Fi (from menus)



Although there is more than one way to create a Skyport account, the steps below illustrate creation from a browser.

If the thermostat is connected to the local Wi-Fi Access Point, but not yet joined to a Skyport account, you may join the thermostat to an account by doing the following:

Select **MENU** from the thermostat's home screen.



Scroll down.



Select Skyport.



Select Skyport Account and follow the onscreen instructions.




1. Open your browser to: <https://JCI.skyportcloud.com>

2. Select “Create account now”.



3. Follow instructions to create an account and add a thermostat to the Skyport account.



Main Menu Buttons – Schedule




Schedule

This thermostat features up to 3 Occupied time periods per 24 hour day.

• View My Schedule

Press a day of the week to view its settings. This may be repeated for each day.




• Edit My Schedule

Press and select day(s) to program

Select individual day(s)

or

Select groups of day(s)



Then press **NEXT**

Press and select a Time Period (Occupied 1, Occupied 2, or Occupied 3) to edit.

TIP:

Occupied 2 will override Occupied 1, and Occupied 3 will override Occupied 1 & 2.



Next


Continued ►

Main Menu Buttons – Schedule

• Edit My Schedule

(Continued)

Adjust Mode, Start Time, Stop Time, and Heat and Cool Setpoints to desired settings. The Time Period May also be Enabled or Disabled. Un-check the enabled box for Time Periods you don't want to use. Press DONE when finished.



When you are finished editing the time periods press

NEXT

Review your program.
Press **SAVE** to keep your program.
Press **EDIT** to make further changes.




Edit

Save

• Unoccupied Settings


Choose your Mode and Heat and Cool setpoints for the Unoccupied period.




Press **MODE** or the MODE icon



On the Home Screen to select to Run or Stop Schedule





Main Menu Buttons – Fan Settings



Fan Settings

The fan may be set to run continuously during Heat, Cool, Auto, and Occupied modes. A Preoccupancy Fan Purge schedule may also be set.

Press to turn fan On to run continuously or Auto for fan to run only with heating or cooling.

• Fan - ON



• Fan - Auto

• Occupied fan state

(On)



Press to turn fan On to run continuously during Occupied mode or Auto for fan to run only with heating or cooling.

• Fan Purge - OFF




Press to turn on Preoccupancy Fan Purge. This feature allows the fan to run for a preset amount of time before Occupied 1 begins.

• Preoccupancy Purge Time (15 mins)



The Preoccupancy Fan Purge timer may be set from 15 minutes to 3 hours in 15 minute increments.





Screensaver

The Screensaver allows you to create custom slideshows.

• Screensaver - OFF

• Screensaver - ON



• Screensaver Setup ▶

• Screensaver Turn On Delay (5m) ▶

How long after a button press for the Screensaver to appear. 1, 3, 5, or 30 minutes

• Screensaver Type (Slideshow) ▶

Slideshow, Digital Clock, Analog Clock

• Change Image After... ▶

15, 30 seconds - 1, 5, or 10 minutes

• Use Theme Images - OFF ▶

Slideshow uses included Theme Images. Off or On

• Randomize Slideshow - OFF ▶

Shuffles slideshow photos in random order

• Show Clock - OFF ▶

Shows the time and date every 5 photos. Off or On

• Home Screen Info - OFF ▶


Shows the mode, setpoints, and temperature after every 10 photos. Off or On.

• Screensaver Preview ▶

Press this button to preview your screensaver operation before returning to the Home Screen.

After the preview, press anywhere on the screen to return to the sub menu.

Main Menu Buttons – Alerts



Main Menu Buttons – Alerts



Alerts

The alerts let you know when your system needs service.

• View Current Alerts

View and reset current service alerts here.

Alerts appear on the bottom bar of the Home Screen.

Press to view and reset current alerts.



• Reset Alerts

Clear and reset current service alerts.

• Set/Edit Reminders

Set service alert runtimes and turn reminders on or off.

• Service Call Reminder - OFF

• Days Until Service Call (360 days)

• Air Filter Reminder - OFF

• Set Max Filter Runtime (500 hrs)

• Set Max Filter Days (180 days)

• UV Lamp Reminder - OFF


• Set Max UV Lamp Runtime (360 days)


• Humidity Pad Reminder - OFF

• Set Max Hum Runtime (360 days)

• Service Information...

View your service company's contact information.







Display

The display brightness options may be adjusted in this menu.

- Active Brightness (80%) ▶

You may select how bright the backlight is while the thermostat is active. The display is active for 3 minutes after last touch, it then goes idle.

- Idle Brightness (30%) ▶

You may select how bright the backlight is while the thermostat is idle.

- Night Dimmer ▶

You may dim the brightness of the touch screen at night.

- Auto Night Dimmer - OFF

The screen can be set to dim automatically at night. Dimming the display can prolong the life of the backlight.

- Set Idle Brightness (50%) ▶

Set the screen brightness for the Night Dimmer. When Night Dimmer is On, the display will go idle 8 seconds after last touch.

- Set Dimmer Schedule ▶

Set the schedule for the Night Dimmer.

• Maintenance ▶

Maintenance allows you to clean and calibrate the touch screen.

• Screen Cleaning ▶

Screen Cleaning Mode disables the touch feature for 15 seconds so the screen may be cleaned without altering any settings.




Use a soft cloth without solvents or abrasive cleaners.

• Touch Calibration ▶


Under normal circumstances, the touch screen should not need to be calibrated.

Touch the center of the targets as they appear on the screen.



Press **FINISH** when done.

When calibration is complete, the thermostat will automatically restart and return to the Home Screen.





Preferences

You may set the type of background that appears on the thermostat Home Screen.

• User Interface Themes (Buildings) ▶

This thermostat has several high quality background themes to choose from.

NOTE: At 7 PM, the background will change to an evening scene.

At 7 AM it will return to a daytime scene.

• Custom Wallpaper ▶

You may choose your own background image by selecting a photo that you have uploaded from an SD memory card.

• Heat/Cool Indicator ▶

You may choose an enhanced indicator of the current status of the HVAC equipment.

- Heat/Cool Indicator - ON/OFF
- Taskbar Red/White - ON/OFF
- Room Temp Red/Blue - ON/OFF
- Mode Status Red/Blue - ON/OFF

• Sound Options ▶

- Beep - ON




- Beep - OFF

Turn the beep sound on or off.

- Beep Sound (Beep 1) ▶

Choose from different beep sounds.





Humidity

The Humidity feature allows the thermostat to control a humidifier or use your air conditioner to dehumidify the space.

IMPORTANT: Aux Output Usage must be set for Hum or Dehum for these settings to take effect.

See: AUX Output Settings on page 60.

• Humidification Settings

- Humidify setpoint (0%) ▶

Adjust Humidify setpoint. (0% - 60%)

- Humidify with heat - OFF ▶

When this step is ON, Humidify will only run with a demand for heat.

- Run fan when humidifying - OFF ▶

When this step is ON, the fan will run with a call for Humidification.

• Dehumidification Settings

- Dehumidify setpoint (99%) ▶

Adjust Dehumidify setpoint. (25% - 99%)

- Run A/C to dehumidify - OFF ▶

When this step is ON, the A/C system will be used for Dehumidification.

- Maximum Overcool (0°) ▶


This specifies how many degrees the A/C system will run past the cool setpoint to satisfy a demand for Dehumidification. (0 - 20 degrees F)

- Reheat - OFF ▶

This turns on electric strip heat during an A/C to dehumidify demand to help maintain desired room temperatures. (Run A/C to dehumidify must be set to ON and the GAS ELEC Dip Switch must be set to ELEC - page 77 - to access this feature).

- Dehumidify only when cooling - ON ▶

Run dehumidification only when HVAC calls for A/C.





Holidays

The Holiday Schedule allows the Color Touch Screen to follow a fully customizable preset, weekly, monthly, and yearly holiday program. The thermostat will stay in Unoccupied settings while Holiday is active.

- Holiday Schedule - OFF

Press to turn Holiday Schedule **On** or **Off**.

- Edit Holidays


Start by selecting a Holiday.

You may continue to select more holidays or you can press the **Repeat** button for recurring holidays.

Pressing a selected holiday will deselect that holiday.

Info

Repeat




Next Month

Using the Repeat Button

Choose to repeat the holiday every week, month or year. Or, press **CANCEL** to go back.

If you choose to repeat the holiday every week, you will be prompted to confirm the day of the week to be repeated.



Using the Info Button

Press the **Info** button to view how non-holidays, holidays, and exceptions to repeating holidays will appear on the Holiday calendar.

Continued ►

• Edit Holidays

(Continued)

Deselecting Holidays

You may deselect a holiday simply by pressing on it.

Press **BACK** to save your changes and return to the Holiday menu.


If you choose to deselect a holiday that is part of a Custom Repeating Program, the screen below will appear.



Marking Non-Holidays

You will now be prompted to mark this day only as a non-holiday or edit **All** repeating holidays that affect this day.

Press **SAVE** to mark only this day as a non-holiday.




If you choose to edit repeating holidays that affect this day, press **NEXT** and the next screen will appear.

Editing Repeating Holidays

If, for example, you choose to repeat the holiday every month, the following screen will appear:

You may now choose to repeat the holiday:

- On the 25th of every month
- On the 4th Monday of every month
- On the last Monday of every month



Press **SAVE** to save your changes and return to Holiday programming.

Continued ►


• Edit Holidays



(Continued)

Editing Repeating Holidays (continued)

You may now delete all repeating custom holidays in this group by pressing the **ON** box to un-check your selection. Press **SAVE** to return to Holiday editing screens.



• Preset Holidays




You may choose from several standard preset holidays to observe. When the preset holidays are set to **ON**, they will be observed every year on that date.


Overriding Holiday Mode

You may override Holiday Mode by pressing the **OVERRIDE** button and choosing the amount of override time desired.

Turning Off Holiday Mode From The Homescreen

You may turn off Holiday Mode by pressing the **MODE** button and then pressing the Holiday **STOP** button.





Main Menu Buttons – Security



Security settings may be set to limit or prevent changes to your thermostat.

• Auto Screenlock

• Auto Screenlock - OFF

• Auto Screenlock - ON

• Set Passcode

(code not set)

NOTE:

Code must be set before Auto Screenlock can be turned on.

Use keypad to enter and confirm passcode.



When the thermostat is locked, the bottom bar of the display will show:



Press **UNLOCK** then enter passcode to access thermostat settings.

• Lock After...

(5 m)

Set the time the screen will automatically lock after the last button press.

• Allow fan/mode changes - NO

Choose to allow mode changes when Auto Screenlock is on.

• Allow setpoint changes - NO

Choose to allow setpoint changes when Auto Screenlock is on.

• Allow override - NO


Choose to allow use of the Override button when Auto Screenlock is on.

• Setpoint Limits

Limits how high or low heating and cooling may be adjusted.

• Maximum Override Time

Select the maximum amount of Override time that will appear as options after pressing the Override button from the home screen when running a schedule. Select times from 30 minutes to 4 hours in 30 minute increments.



Main Menu Buttons – Information




Information

This button contains valuable service and system runtime information.

• View Runtime Graphs ▶


Track your system's runtime/energy usage.

• Last 7 Days - Cooling ▶



Press the information icon to learn more about each graph.

• Last 7 Days - Heating ▶



***NOTE:** The runtime graphs are updated at 12:00 AM each day.

Press anywhere on the screen to return to the submenu.

• Last 7 Days - Override ▶

Press to view a graph of override runtime information.

• Delete Runtime Data ▶


Press to delete your current equipment runtime information.

• Who To Call For Service ▶


Your service company's contact information is displayed here.





Main Menu Buttons – Settings



(Continued next page)









Thermostat heating and cooling options are found in this menu.

• Thermostat Name ▶

Use keypad to name your thermostat. The name is displayed on the Home Screen.

(Up to 14 characters)

Name appears here



• Available Modes (all) ▶

Choose the desired modes the thermostat will use: Heat, Cool, Heat & Cool, or Auto (All). For example, if you only have a heater, choose Heat, and only Heat & Off modes will be available. This will simplify the operation for the user.

• SD Card ▶

Import and export files to and from the thermostat. See the **ColorDisplay Desktop app** instructions for further details.

• Import Settings from SD Card ▶

Upload files from ColorDisplay Desktop App or another thermostat.

• Export Settings to SD Card ▶

Export files from one thermostat and import them into others.

***NOTE:** A 2GB SD card is recommended. To import and export settings, the SD card must contain the same version of the firmware as the thermostat. ColorDisplay Assistant will keep the firmware current.

• General Setup ▶

• Units (F) ▶

- Fahrenheit (F)
- Celsius (C)

• General Setup ▶

(Continued)

• Language ▶

(en)

- English
- Spanish/Español
- French/Français

• Smart Recovery - OFF

• Smart Recovery - ON ✓

Smart Recovery turns on the heat before the Occupied start time to bring the room temperature to the Occupied setpoint at the start of the Occupied time period. Please allow 4-8 days for Smart Recovery time to adjust. When used with a heat pump, electric strip heat will be disabled while Smart Recovery is active.

• Installation Settings ▶

• Heat & Cool Stages (1h1c) ▶

• Heat & Cool Stages (1h1c) ▶

Up to 2 Stages Cooling and 4 stages Heating.

• Compressor Stages (1h1c) ▶

Up to 2 compressors.

• Aux Heat Stages (1h1c) ▶

0 to 2 stages of Aux Heating.

} Only available when dip switch is set for Heat Pump operation.

• Timers & Deadbands ▶

• Cycles Per Hour (6) ▶

At 6 cycles per hour, the HVAC unit will only be allowed to energize once every 10 minutes. The Cycles Per Hour limit may be overridden and reset by pressing the WARMER or COOLER buttons.
(2, 3, 4, 5, 6, No Limit)

• Installation Settings ▶

(Continued)

• Timers & Deadbands ▶

(Continued)

The Deadband is the number of degrees or minutes that the thermostat waits before it initiates the stages of heating or cooling.

1st Stage Deadband Specifies the minimum temperature difference between the room temperature and the desired setpoint before the first stage of heating or cooling is allowed to turn on. For example, if the heat setpoint is 68° and the 1st Stage deadband is set to 2 degrees, the room temperature will need to drop to **66 degrees** before the heat turns on.

• 1st Stage Deadband (2°) ▶

(1 - 6 deg. F)

• 2nd Stage Deadband ▶

• 2nd Stage Deadband (2°) ▶

Number of degrees past 1st stage before 2nd stage turns on. (0 - 10 deg. F)

• 2nd Stage Timer (2mins) ▶

Number of minutes past 1st stage before 2nd stage turns on. (0 - 60 mins.)
(The 2nd stage deadband must also be met)

• 2nd Stage Turnoff Point (Deadband) ▶

Deadband or Setpoint.

• 3rd Stage Deadband ▶

• 4th Stage Deadband ▶

The 3rd and 4th stage deadband settings have the same adjustable steps as 2nd stage deadband.


• Automated Demand Response ►

Overview

ColorDisplay thermostats support the handling of specific signals from the utility provider. The utility generated signals carry pricing information and/or setback actions that alter the comfort settings of the thermostat in order to reduce energy usage on demand. This is known as **Automated Demand Response** or ADR for short. You must register to participate in a utility sponsored program, if offered by your local utility, to take advantage of this feature.

SKYPORT CLOUD SERVICES

From the web application the user will select **Thermostat Settings** from the left column. Then the **Demand Response** button is selected.



The Demand Response configuration page, shown below, is where the thermostat is configured to respond to the energy provider's signals. It also sets operational parameters for the thermostat.

The left column of the ADR configuration page allows or prevents access by the utility. Here communication with the utility and your thermostat may be turned On or Off.

The screenshot shows the 'Office - Configuration' window with a sidebar on the left and a main configuration area on the right. The sidebar contains buttons for Profile, Runtime Data, Sensors, Notifications, Alerts, Schedule, and Thermostat Settings. The main area is titled 'Automated Demand Response' and has two tabs: 'Configuration' and 'Overview'. The 'Configuration' tab is active, showing a 'Demand Response' section with 'ON' and 'OFF' buttons. Below this is a text box explaining Demand Response. To the right are sections for 'Min & Max Settings', 'Static Settings', 'Offset Settings', and 'Price Settings'. The 'Save' button is at the bottom right.

Office - Configuration

Profile
Rename your thermostat or change its location

Runtime Data
View Heat & Cool runtime

Sensors
View sensors connected to this thermostat

Notifications
Quickly add and remove thermostat notifications

Alerts
View current alerts for this thermostat


Schedule
Modify your thermostat schedule

Thermostat Settings
Change your thermostat settings

Delete Thermostat

Automated Demand Response

Configuration Overview



Demand Response

☒ ON ☐ OFF

What is Demand Response?

It is a way for energy suppliers to automatically reduce load during high energy use periods. This reduces the strain on the power grid while offering incentives to individuals who participate in demand response events.

Min & Max Settings

Event Max Cool Setpoint 80°F	Event Min Heat Setpoint 80°F
---------------------------------	---------------------------------

Static Settings

Static Cool Setpoint 72°F	Static Heat Setpoint 80°F
------------------------------	------------------------------

Offset Settings

Cool Setpoint Offset +2	Heat Setpoint Offset +3
----------------------------	----------------------------

Price Settings

Price Trigger
\$ 0.5

Dependent Action
Observe Setpoint Offsets

Cancel Save


The right column of the ADR configuration page is where the occupant adjusts the operational parameters for ADR. The utility may send up to 3 types of ADR signals to Skyport. These are: **1) Pricing** for the cost of energy, **2) An Offset** to the occupants' comfort setpoints, and **3) a signal** to enforce discrete or Static setpoints.

The Maximum Cooling Setpoint and Minimum Heating Setpoints for ADR events are adjusted here.

The Static Settings are applied when the utility sends a signal to allow the occupant to enforce their own discrete temperature settings during an ADR event.

The Offset Settings allow the utility to modify the Cool or Heat setpoints by the value set here during an ADR event.

A Price Trigger setting allows the occupant to set the maximum cost of energy threshold. When this threshold is exceeded the Price dependent action is enforced. This Price Trigger and Dependent action is enforced independent of an ADR event, as long as the utility sends 'real-time' pricing.



Main Menu Buttons – Settings

Selecting the Overview tab of the ADR page will cause a summary of ADR events to be displayed.

The screenshot displays the 'Office - Configuration' window. On the left is a sidebar menu with options: Profile, Runtime Data, Sensors, Notifications, Alerts, Schedule, and Thermostat Settings. The main area shows the 'Automated Demand Response' window with two tabs: 'Configuration' and 'Overview'. The 'Overview' tab is active, showing a table of ADR events. Below the table are 'Cancel' and 'Save' buttons. At the bottom of the main area are icons for Security, Humidity, Settings, and Demand Response.


Event Id	Event Type	Status	Start Time	Stop Time
1233407644	Price	Success	08/10/2014 1:00pm	08/10/2014 2:00pm
1233407644	Price	Success	08/15/2014 4:00pm	08/15/2014 5:00pm

- Automated Demand Response ►

Utility and Program setup must be done at the Skyport Cloud Services account. From the thermostat Home Screen, press the 'Menu' button, then select 'Settings'.



From the above screen the 'Automated Demand Response' button is pressed.



By selecting ADR – On, the user can participate in ADR events triggered by their utility, or price dependent events.




Selecting the 'Price Dependent Action' button allows the user to determine what action is taken when the price rises above the set threshold.




In the above example; if the price threshold is exceeded, the thermostat will invoke the 'Offset Setpoints' configured for an ADR event until the event is over.

Please note that the Threshold price may only be set in the Skyport Cloud Services account.





The user may limit the maximum Cooling Setpoint.






The user may limit the minimum Heating Setpoint.






The user may adjust the ADR Cooling 'static' Setpoint.






The user may adjust the ADR Heating 'static' Setpoint.





The user may adjust the ADR Cool offset. During an ADR event the cooling setpoint will be adjusted by the amount of degrees configured in this step.





The user may adjust the ADR Heat offset. During an ADR event the heating setpoint will be adjusted by the amount of degrees configured in this step.




Main Menu Buttons – Settings

When an ADR event is pending, and hasn't started yet, there will be a yellow leaf on the top bar. This will be accompanied by associated text as shown below.




During an ADR event there will be a green leaf on the top bar. This will be accompanied by associated text as shown below.




Main Menu Buttons – Settings

If a Warmer or Cooler button is pressed during an active ADR event, then the user is presented with this opt-out screen.



If a pricing triggered ADR event is enabled, there will be a green leaf on the top bar along with the actual cost of energy. This will be accompanied by associated text as shown below



Main Menu Buttons – Settings

• Installation Settings ▶

(Continued)

• Heat Pump Settings ▶

(Only available when dip switch is set for Heat Pump operation.)

• Heat Pump Lockout - DISABLED ▶

• Heat Pump Lockout - ENABLED ✓

Turns on Heat Pump Lockout.

• HP Lockout Outdoor Temp (65°) ▶

Heat Pump will not run below this temp. (0 - 75 deg. F)

• Aux Heat Lockout - DISABLED ▶

• Aux Heat Lockout - ENABLED ✓

Turns on Aux Heat Lockout.

• Aux Heat Lockout Temp (65°) ▶

Aux Heat will not run above this temp. (0 - 75 deg. F) **GAS/EL** or **HP** dip switch must be set for **HP** and **GAS** or **ELEC** dip switch must be set for **ELEC**.

• Installation Settings ▶

(Continued)

• AUX Output Settings ▶

Allows the W3/AUX output to be used for Heating, Humidification, or Dehumidification.

• AUX output usage ▶

(W3)

IMPORTANT: Aux Output Usage must be set for Hum or Dehum before any settings will take effect in the Humidity Main Menu.



• AUX output polarity ▶

(NO)

The AUX Output polarity may be set for Normally Open or Normally Closed to accommodate different types of humidification and dehumidification equipment.

• Installation Settings ▶ (Continued)

• Fan Off Delay (0s) ▶

Runs the fan for a short time after Cooling or electric strip heat turns off to increase system efficiency. (0 - 120 Secs.)

• Sensor Settings ▶

• Control Sensor (thermostat) ▶

When a remote sensor is connected to the thermostat, the user may choose which sensor source is used to measure room temperature.

- Thermostat Sensor Only
- Wired Sensor Only
- Average All Wireless Sensors
- Average Wired/Thermostat
- Average Wireless/Thermostat
- Average all available Sensors

• Wireless Sensors (remote) ▶

The wireless sensor may be used as follows:

- Add New Sensor
- Remote Sensor

• Wired Sensor Use (remote) ▶

The wired sensor may be used as follows:

- Use as an Outdoor sensor
- Use as a Remote Sensor
- Use as a Supply Sensor
- Use as a Return Sensor

• Dealer Information ▶

A Dealer may enter their company contact information for the customer to use when they need service. This will appear when the “Who To Call For Service” button is pressed in the Information Menu.

Use the keyboard to enter your information.

- **Dealer Name**
 - **Contact Name**
 - **Dealer Phone**
 - **Dealer Email**
 - **Dealer Website**
- Please use ColorDisplay Desktop App to add Dealer's logo.**
(See page 71)



• Upgrade Firmware ▶

Press to upgrade the thermostat firmware. The SD Card must be in the thermostat SD Card reader and contain the valid firmware. If an error message appears, confirm with the ColorDisplay Desktop APP that firmware is up to date or simply try reinserting the SD card.

If you are connected to Skyport Wi-Fi and you receive an Alert that new firmware is available, simply press the Upgrade Firmware button to upgrade wirelessly.

Note: Occasionally an update that requires a large amount of data is not possible to do wirelessly. In this case an update using an SD card will be required.

• Delete Custom Images ▶


Press to delete the custom photos you uploaded to the thermostat.

• Factory Defaults ▶

Press to reset the thermostat back to the factory settings.

• Restart Thermostat ▶

If needed, press here to restart the thermostat.






• Wi-Fi Enabled ▶

This option allows the wifi radio to be turned off or on.


• Wi-Fi Status ▶


It is here that you will find helpful information regarding the connectivity status of your thermostat, including the thermostat's ID.



• Wi-Fi Setup ▶

Choose your network from the list and enter the network password.

 If your network does not appear in the list, hit the refresh button.



• Local API Option ▶

Turning on the local API allows 3rd party software to interface with your thermostat, such as a home automation system.

Main Menu Buttons – Wi-Fi

This is the default with the local API OFF.

- Local API - OFF
- API Protocol (http) ▶

To turn on the HTTP Local API select **Local API**

- Local API - ON ✓
- API Protocol (http)

Press **BACK** to return to previous screen.

If a Secure API is required, then select **API Protocol**

- Local API - OFF
- API Protocol (http) ▶

Upon pressing **API Protocol**, the following screen will appear.


- HTTP ✓
- HTTPS

Then select **HTTPS** and press **BACK**


- HTTP
- HTTPS ✓

Main Menu Buttons – Settings


Upon pressing **BACK**, the screen will look like this.



Select **Basic Auth User**, and enter the appropriate information on the screen below and press **DONE** to save.



Select **Basic Auth Password** as the next step.



• Basic Auth Password ▶

Select **Basic Auth Password** and enter the appropriate information on the screen below and press **DONE** to save.

The screenshot shows a virtual keyboard interface for entering a password. At the top, there is a text input field with a red 'X' icon and the text "(64 remaining)". Below the input field is a standard QWERTY keyboard layout. The bottom of the screen features three buttons: a "BACK" button with a left arrow, a "Basic Auth Password" button, and a "DONE" button with a green checkmark icon.


The last step is to turn the **Local API** on as shown below.

• Local API - ON ✓

• API Protocol (https)

• Basic Auth User ▶

• Basic Auth Password ▶



Pressing this button will let you know if you are paired with a Skyport account. If not, then you may follow prompt and instructions to create an account and add the thermostat to the account.


Main Menu Buttons – Emergency Heat



Emergency Heat

The Emergency Heat function is only available if your thermostat is set to control a Heat Pump.

To initiate the Emergency Heat feature, press the Emergency Heat button. During Emergency Heat operation, the thermostat will turn on the fan and substitute auxiliary stages of heat for the first/second stages of heat. The heatpump will not be available for heating but can be used for cooling. To exit Emergency Heat, press the Emergency Heat button.




The ColorDisplay Desktop App



ColorDisplay Desktop App may be downloaded at no charge at:

<http://jcithermostats.com/colordisplay/desktop-app/>




Every time the user runs the ColorDisplay Desktop App software, it automatically connects to the Johnson Controls® ColorDisplay website in the background and updates the software and firmware (the operating system for touch screen) at no cost.

The ColorDisplay Desktop App allows you to use your computer to:

- Upload photos for background and slideshow images
- Update thermostat firmware

Uploading Photos and Settings to your thermostat

When you are finished adding and editing photos and settings, click on **Save to SD**. When prompted, remove the SD card from the SD card reader on your computer.



Save to SD

*NOTE: A 2GB SD card is recommended.

At the thermostat:

Insert the SD card into the SD Card Slot.

Press

MENU

then



Next, press



Settings



SD Card Slot

Press

• SD Card



Then press

• Import Settings from SD Card



Select the items to import into your thermostat then press

NEXT




Your thermostat will automatically save your new photos and settings in its internal memory. When finished, you may remove the SD card. It is not needed for normal thermostat operation.

Remove and Replace the Old Thermostat

To install the thermostat properly, please follow these step by step instructions. If you are unsure about any of these steps, call a qualified technician for assistance.

- Assemble tools: Flat blade screwdriver, wire cutters and wire strippers.



- Make sure your Heater/Air Conditioner is working properly before beginning installation of the thermostat.
- Carefully unpack the thermostat. Save the screws, any brackets, and instructions.
- Turn off the power to the Heating/Air Conditioning system at the main fuse panel. Most residential systems have a separate breaker for disconnecting power to the furnace.
- Remove the cover of the old thermostat. If it does not come off easily, check for screws.
- Loosen the screws holding the thermostat base or subbase to the wall and lift away.
- Disconnect the wires from the old thermostat. Tape the ends of the wires as you disconnect them, and mark them with the letter of the terminal for easy reconnection to the new thermostat.
- Keep the old thermostat for reference purposes, until your new thermostat is functioning properly.

Wire Connections

If the terminal designations on your old thermostat do not match those on the new thermostat, **refer to the chart below or the wiring diagrams that follow.**

Wire from the old thermostat terminal marked	Function	Install on the new thermostat connector marked
G or F	Fan	G
Y1, Y	Cooling	Y1
W1, W	Heating	W1/O/B
Rh, R, M, Vr, A	Power	R
C	Common	C
O/B	Rev. Valve	W1/O/B*
W2	2nd Stage Heat	W2
Y2	2nd Stage Cooling	Y2
W3	3rd Stage Heat	W3
OUT -	Outdoor Sensor	SENSOR
OUT +	Outdoor Sensor	SENSOR

* O/B is used if your system is a Heat Pump.

Before you go any further, determine what your existing wiring and equipment situation is.

- A. If you have a **Heating only system** without Air Conditioning, the JCI thermostat will require **3 wires**: R (24Vac), C (24Vac) and W (Heat). Most systems that only have Heating use very simple thermostats that require 2 wires: the R (24Vac) and W (Heat). The JCI thermostat requires **3 wires** to the thermostat. In this case an Add-a-Wire accessory will not work and it will be necessary to install another wire for the C (24Vac) connection.
- B. If you have a **single stage fossil fuel heater with air conditioning**, the JCI model will require **5 wires** for independent fan control. They are R (24Vac), C (24Vac), W (Heat), Y (Cooling), and G (Fan). You may connect only 4 wires, as instructed in the “Making 4 Wires Work When 5 Wires Are Required” section on page 72.

If there are only 4 wires present that are connected to the existing thermostat, there are at least 2 options available to connect the JCI thermostat:

1. Use the 4 wires as instructed in the “Making 4 Wires Work When 5 Wires Are Required” section on page 74, and note that the fan will only operate with a Heating or Cooling demand.
 2. Pull new thermostat wire from the HVAC equipment to the thermostat so that there are at least 5 wires available.
- C. If you have a **multi-stage HVAC system comprised of a fossil fuel heater with air conditioning**, the JCI thermostat will require the 5 wires mentioned above (R, C, W, Y, G) plus an additional wire for each additional stage of Heating or Cooling. You may reduce the 5 wire requirement to 4 if you give up independent fan control following the instruction in the “Making 4 Wires Work When 5 Wires Are Required” section on page 74, or use the optional Add-A-Wire accessory.

- D. If you have a **heat pump without aux heat**, the JCI model will require 5 wires: R (24Vac), C (24Vac), W1/O/B (Reversing Value), Y (1st Stage Compressor), and G (Fan).

If you are short 1 wire, there are at least 2 options available to connect the JCI thermostat:

1. Use the available wires as instructed in the “Making 4 Wires Work When 5 Wires Are Required” section on page 74 and note that the fan will only operate with a Heating or Cooling demand.
2. Pull new thermostat wire from the HVAC equipment to the thermostat so that there are at least 5 wires available.

- E. If you have a **heat pump with aux heat**, the JCI model will require 6 wires: R (24Vac), C (24Vac), W1/O/B (Reversing Value), Y (1st Stage Compressor), W2 (Aux Heat), and G (Fan).

If you are short 1 wire, there are at least 2 options available to connect the JCI thermostat:

1. Use the available wires as instructed in the “Making 5 Wires Work When 6 Wires Are Required” section on page 75 and note that the fan will only operate with a Heating or Cooling demand.
2. Pull new thermostat wire from the HVAC equipment to the thermostat so that there are at least 6 wires available.

Making 4 Wires Work When 5 Wires Are Required

If you would like to install the JCI thermostat using only 4 wires when 5 are required, follow the directions below. You will need a screwdriver along with a 3" long piece of thermostat wire to use as a jumper:


1. Make sure the power is off.
2. Label and disconnect wires at the thermostat. Please note the color and corresponding wire designator with each color. *For example: The R wire is red and the W wire is white and so on.* You will need this information handy for the next step at the HVAC equipment.
3. At the HVAC equipment end of the thermostat wires (usually at the furnace), locate the terminals that the wires are attached to.
4. Remove the "G wire" from the terminal marked G.
5. Place the "G wire" on terminal C.
6. Place one end of the 3" long jumper on terminal G.
7. Place the other end of the 3" long jumper on terminal Y. Please note that there will be more than 1 wire on terminal Y.
8. When connecting the wires to the JCI thermostat, note that the wire that was previously connected to the G terminal of the old thermostat will now be required to be connected to the C terminal on the JCI thermostat. **All other wires** will be connected such that the connections on **each end of the individual wires match terminal designations.** *For example: Connect the yellow wire on the thermostat end to the Y terminal on the thermostat. The yellow wire will be connected to the Y terminal on the HVAC equipment end also.*

Making 5 Wires Work When 6 Wires Are Required

If you have a system that requires 6 wires, and you would like to install the JCI thermostat using only 5 wires, follow the directions below. You will need a screwdriver along with a 3" long piece of thermostat wire to use as a jumper:

1. Make sure the power is off.
2. Label and disconnect wires at the thermostat. Please note the color and corresponding wire designator with each color. *For example: The R wire is red and the W wire is white and so on.* You will need this information handy for the next step at the HVAC equipment.
3. At the HVAC equipment end of the thermostat wires (usually at the furnace), locate the terminals that the wires are attached to.
4. Remove the "G wire" from the terminal marked G.
5. Place the "G wire" on terminal C.
6. Place one end of the 3" long jumper on terminal G.
7. Place the other end of the 3" long jumper on terminal Y. Please note that there will be more than 1 wire on terminal Y.
8. When connecting the wires to the JCI thermostat, note that the wire that was previously connected to the G terminal of the old thermostat will now be required to be connected to the C terminal on the JCI thermostat. **All other wires** will be connected such that the connections on **each end of the individual wires match terminal designations.** *For example: Connect the yellow wire on the thermostat end to the Y terminal on the thermostat. The yellow wire will be connected to the Y terminal on the HVAC equipment end also.*

The T9100 Thermostat Backplate




NOTE:


The backplate does not fully cover a full size vertical junction box. The ACC-WALLPLT touch screen wallplate or a single-gang, horizontally mounted junction box would be needed for that type of installation.

To remove the thermostat backplate:

Using the Finger Pull Areas, pull the front housing away from the backplate.



Look for these tabs to locate the pull areas



Pull out with thumbs in these areas

W3/AUX

3rd stage heat circuit/2nd stage aux heat/humidification/dehumidification

W2

2nd stage heat circuit/1st stage aux heat

W1/O/B

1st stage heat circuit/reversing valve

Y2

2nd stage compressor relay

Y1

1st stage compressor relay

G

fan relay

R

24 VAC return

C

24 VAC common


SENSOR

remote/outdoor/supply/return sensor connections

IMPORTANT: This thermostat requires both R (24 VAC Return) and C (24 VAC Common) be connected to the backplate terminals.

Explanation of Thermostat Dip Switches

Dip switches are located on the back of the thermostat



GAS/EL HP



OR

GAS/EL HP



This dip switch configures the thermostat to control a conventional gas/electric system or a heat pump. If your system is anything other than a heat pump, leave this switch set for GAS/EL.*

*For some commercial heat pumps, this switch may need to be set for GAS/EL. Consult the commercial heat pump literature.



OR



When the GAS/EL or HP dip switch is configured for HP, this dip switch (O or B) must be set to control the appropriate reversing valve. If O is chosen, the W1/O/B terminal will energize in cooling. If B is chosen, the W1/O/B terminal will energize in heating.

1. When **GAS/EL or HP** is set for **GAS/EL**:

This switch (GAS or ELEC) controls how the thermostat will control the Fan (G) terminal in heating mode. When **GAS** is chosen, the thermostat **will not** energize the Fan (G) terminal in heating. When **ELEC** is chosen the thermostat **will** energize the fan in heating.



OR



GAS/ELEC

GAS/ELEC

2. When **GAS/EL or HP** is set for **HP**:

This switch (GAS or ELEC) defines the Aux Heat type. When **GAS** is chosen, the auxiliary heat will not be allowed to run during heat pump operation. When using a Dual Fuel system, set this switch for **GAS**. When **ELEC** is chosen, up to two stages of auxiliary strip heat will be allowed to run.

Sample Wiring Diagrams with Dip Switch Positions

Conventional Heating and Cooling Systems

2 Wire, Heat Only

Residential & Commercial 1 Stage Heating with no Fan.

The thermostat will not work with 2 wires. Pull new wire.



3 Wire, Heat Only

Residential & Commercial 1 Stage Heating with no Fan.

R 24VAC Power
C 24VAC Common
W1/O/B 1st Stage Heat



4 Wire, Cool Only

Residential & Commercial 1 Stage Cooling.

R 24VAC Power
C 24VAC Common
Y1 1st Stage Cool
G Fan



5 Wire, 1 Stage Cooling, 1 Stage Heat

Residential & Commercial 1 Stage Cooling, with 1 stage Gas Heat.

R 24VAC Power
C 24VAC Common
W1/O/B 1st Stage Heat
Y1 1st Stage Cool
G Fan



5 Wire, 1 Stage Cooling, 1 Stage Heat

Residential & Commercial 1 Stage Cooling, with 1 stage Electric Heat.

R 24VAC Power
C 24VAC Common
W1/O/B 1st Stage Heat
Y1 1st Stage Cool
G Fan



8 Wire, 2 Stage Cooling, 3 Stage Heat

Residential & Commercial 2 Stage Cooling, with 3 stage Gas Heat.

R 24VAC Power
C 24VAC Common
W1/O/B 1st Stage Heat
W2 2nd Stage Heat
W3/AUX 3rd Stage Heat
Y1 1st Stage Cool
Y2 2nd Stage Cool
G Fan



Sample Wiring Diagrams with Dip Switch Positions

Heat Pump Systems

5 Wire, 1 Stage Cooling, 1 Stage Heat

Residential & Commercial Heat Pump with
'O' Reversing Valve

R	24VAC Power
C	24VAC Common
W1/O/B	Reversing Valve
Y1	1st Stage Compressor (Cool or Heat)
G	Fan

GAS/EL		HP
O		B
GAS		ELEC

6 Wire, 1 Stage Cooling, 2 Stage Heat

Residential & Commercial Heat Pump with
'O' Reversing Valve

R	24VAC Power
C	24VAC Common
W1/O/B	Reversing Valve
Y1	1st Stage Compressor (Cool or Heat)
W2	Aux Heat
G	Fan

GAS/EL		HP
O		B
GAS		ELEC

7 Wire, 2 Stage Cooling, 3 Stage Heat

Residential & Commercial Heat Pump with
'O' Reversing Valve.

R	24VAC Power
C	24VAC Common
W1/O/B	Reversing Valve
W2	3rd Stage Heat
Y1	1st Stage Compressor (Cool or Heat)
Y2	2nd Stage Compressor (Cool or Heat)
G	Fan

GAS/EL		HP
O		B
GAS		ELEC

(Number of Compressor Stages set to 2)

8 Wire, 2 Stage Cooling, 4 Stage Heat

Residential & Commercial Heat Pump with
'O' Reversing Valve.

R	24VAC Power
C	24VAC Common
W1/O/B	Reversing Valve
W2	3rd Stage Heat
W3/AUX	4th Stage Heat
Y1	1st Stage Compressor (Cool or Heat)
Y2	2nd Stage Compressor (Cool or Heat)
G	Fan


GAS/EL		HP
O		B
GAS		ELEC

(Number of Compressor Stages set to 2)

Sample Wiring Diagrams

Outdoor Sensor: ACC-RSEN Temperature Sensor 10K ohm sensor at 77F/25C. Negative Temperature Coefficient.


Use 18-22 gauge thermostat wire.



Indoor Remote Sensor with Override Button: ACC-RSEN-OVR Temperature Sensor 10K ohm sensor at 77F/25C. Negative Temperature Coefficient.

(see page 59 for setup instructions)

Use 18-22 gauge thermostat wire.




Sample Wiring Diagrams

Humidification

**AUX Output Usage
must be set for Hum**


**Use 16-24 gauge
thermostat wire.**



Dehumidification

**AUX Output Usage
must be set for Dehum**

**Use 16-24 gauge
thermostat wire.**



- **SYMPTOM:** The thermostat touch screen buttons are not responsive.
CAUSE: The touch screen is out of calibration.
REMEDY: Remove the thermostat from the backplate. Push the thermostat back onto the backplate, while keeping your finger pressed firmly against the center of the touch screen, until the Calibration screen appears. Re-calibrate the touch screen. *See Touch Calibration section of full user's manual (page 23).*
- **SYMPTOM:** The display is blank.
CAUSE: Lack of proper power.
REMEDY: Make sure the power is on to the HVAC and that you have 24vac between **R & C**.
- **SYMPTOM:** The air conditioning does not attempt to turn on.
CAUSE: The cooling setpoint is set too high.
REMEDY: Lower the cooling setpoint or lower the cooling set-point limit. *See Setpoint Limits (page 33).*
- **SYMPTOM:** The heating does not attempt to turn on.
CAUSE: The heating setpoint is set too low.
REMEDY: Raise the heating setpoint or raise the heating setpoint limit. *See Setpoint Limits (page 33).*
- **SYMPTOM:** When controlling a residential heat pump, and asking for cooling, the heat comes on.
CAUSE: The thermostat reversing valve dip switch is set for **"B"**.
REMEDY: Set the reversing valve jumper for **"O"**.
- **SYMPTOM:** When calling for cooling, both the heat and cool come on.
CAUSE: The thermostat equipment dip switch is configured for **"HP"** and the HVAC unit is a Gas/Electric.
REMEDY: Set the equipment dip switch for **"Gas"**.
- **SYMPTOM:** Air handler control board fuse blows when thermostat is attached to backplate with power on, but does not blow until the thermostat is placed onto the backplate.
CAUSE: The Outdoor sensor and/or sensor wiring is shorted.
REMEDY: Check/replace Outdoor sensor and/or sensor wiring.

A

Accessories 61

Active Brightness, 23

Alerts, 22

view current, 22

reset, 22

set/edit reminders, 22

See also Runtime

Aux Heat Lockout, 59

Aux Output, 60

Auto

adjust temperature, 6

changeover, 6

fan, 6

mode, 6

Auto Screenlock, 35

Available Modes, 42

B

B Reversing Valve, 74

Backgrounds, 27

Backlight, 24

Backplate, 79

Beep, 27

Buttons,

Back, 1

Cooler, 1, 6

Fan, 1, 6

Home, 1

Mode, 1, 6

Menu, 1

Override, 7

Warmer, 1

C

Connections, 74

Calibration, 62

Celsius, 42

Choose Network, 25, 65

Cleaning, 5, 25

Clock

Display 1

Setting, 9

**ColorDisplay Desktop
App**, 71

Cool

1st stage deadband,
see Deadband

2nd stage deadband,
see Deadband

Hours of runtime, 37

Custom Wallpaper, 27

Cycles Per Hour, 43

D

Daylight Savings, 10

Deadband

1st stage, 44

2nd stage, 44

3rd stage, 44

4th stage, 44

Dealer Information, 37, 63

Delay

Fan-off, *see Fan*

Time between stages,
see Time Delay

Dehumidification, 29, 84

Dimmer, 21

Dip Switches

ELEC, 80

electric heat, 80

GAS/EL, 80

GAS, 80

HP, 80

heat pump, 80

O, 80

B, 80

Disabled Buttons

see Security

Display, 1, 2, 24

E

Electric Heating

Aux heat, 59

Dip switch setting, 80

Lockout, 59

Emergency Heat, 70

Energy Usage

Cool, 37

Heat, 37

Aux heat, 37

F

Factory Defaults

resetting, 63

Fahrenheit, 42

Fan

button function,
see Buttons

off time delay, 61

on during heat,

see Electric Heat

runtime, 37

2nd stage heat, *see*
Emergency Heat

G

Gas/Electric Furnace

dip switch, 80

General Setup, 42

H

Heat

1st stage

deadband, *see*

Deadband

emergency heat, 70

hours of runtime, 37

2nd stage deadband,

see Deadband

electric strip heat,

see Aux Heat

hours of runtime, 37

3rd stage deadband,

see Deadband

4th stage deadband,

see Deadband

timer, 44

turnoff point, 44

electric/heat pump, 59

mode, 6

program, *see Schedule*

runtime, *see Runtime*

setpoint, 6

Heat/Cool Indicator, 27

Heat Pump

aux heat, 41, 59

aux heat lockout, 59

emergency heat, 67

heat pump lockout, 59

dip switch setting, 59

multi-stage, 59, 72

Holiday, 7, 31

Humidity, 29, 60, 84

I

Idle Brightness, 24

Information, 37

Installation Settings, 43

Installation, 73

K

Keypad, 35

L

Language, 43

Lock

see Security

Logo, 63

M

- Main Menu, 1**
- Maintenance, 25**
- Manual**
 - changeover, 6
 - cool, 6
 - heat, 6
- Mode, 1, 6**
- Mode Restrictions, 6**
- Morning Warm-up,**
see Smart Recovery
- Multi-Stage Operation, 6**

N

- Network Password, 65**
- Night Dimmer, 24**
- Non-Programmable
Thermostat, ii**

O

- O Reversing Valve, 79**
- Off Mode, 6**
- Outdoor**
 - high and low temp, 6

- sensor, 61
- viewing temp, 1

- Overcool, 29**
- Override, 7**

P

- Passcode, 35**
- Photos, 20, 63, 72**
- Preferences, 27**
- Program**
 - daily schedule, 15, 16

R

- Reheat, 29**
- Remote Sensor, 61, 83**
- Reset**
 - alert messages, 22
 - thermostat settings,
see Factory Defaults
 - runtime,
 - fan/filter, 18
 - UV light, 22
- Reversing Valve, 80**
- Runtime**
 - resetting, *see Reset*
 - service filter, 22
 - UV light, 22
 - viewing, 22, 37

S

- Schedule**
 - turn on/off, 15
 - view, 15
 - edit, 15
- Screen Cleaning, 5, 25**
- Screensaver**
 - turn on/off, 20
 - setup, 20
 - preview, 20
- SD Card, 42**
- 2nd stage turn off**
 - temperature, 44
- Security, 35**
- Sensor**
 - outdoor, 61, 83
 - remote, 61, 83
 - thermostat, 61
- Service**
 - alerts, 22
 - information, 37
- Set Clock, *see Clock***
- Setpoint**
 - cool, 6
 - heat, 6
 - limits, 35
- Settings, 43**
- Skyport Service ON/
OFF, 69**
- Smart Recovery, 43**
- Sound Options, 27**
- Stages, 43**

T

Terminals,

see Backplate

Test Outputs, 62

Themes, 27

Thermostat Sensor

calibrate, 59

Three Stage Heat, 44

Time, *see Clock*

Timers, 43

Time Delay,

compressor lockout, 59

cycles per hour, 43

1st stage to 2nd stage, 44

2nd stage to 3rd stage, 44

3rd stage to 4th stage, 44

Time schedule,

see Schedule

Touch Calibration, 25, 62

U

Upgrade Firmware, 63

User Interface Themes, 27

UV Light,

resetting, 22

runtime, *see Runtime*

setting, *see Runtime*

W

W1, 74

W2, 74

W3, 74

Wallpaper, 27

Warranty, 91

Wiring, 74

gas/electric, 80

heat pump, 82

Y

Y1, 74, 79

Y2, 74, 79

Three-Year Warranty - This Product is warranted to be free from defects in material and workmanship. If it appears within three years from the date of original installation, whether or not actual use begins on that date, that the product does not meet this warranty, a new or remanufactured part, at the manufacturer's sole option to replace any defective part, will be provided without charge for the part itself provided the defective part is returned to the distributor through a qualified servicing dealer.

THIS WARRANTY DOES NOT INCLUDE LABOR OR OTHER COSTS incurred for diagnosing, repairing, removing, installing, shipping, servicing or handling of either defective parts or replacement parts. Such costs may be covered by a separate warranty provided by the installer.

THIS WARRANTY APPLIES ONLY TO PRODUCTS IN THEIR ORIGINAL INSTALLATION LOCATION AND BECOMES VOID UPON REINSTALLATION.

LIMITATIONS OF WARRANTIES – ALL IMPLIED WARRANTIES (INCLUDING IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY) ARE HEREBY LIMITED IN DURATION TO THE PERIOD FOR WHICH THE LIMITED WARRANTY IS GIVEN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE MAY NOT APPLY TO YOU. THE EXPRESSED WARRANTIES MADE IN THIS WARRANTY ARE EXCLUSIVE AND MAY NOT BE ALTERED, ENLARGED, OR CHANGED BY ANY DISTRIBUTOR, DEALER, OR OTHER PERSON WHATSOEVER.

ALL WORK UNDER THE TERMS OF THIS WARRANTY SHALL BE PERFORMED DURING NORMAL WORKING HOURS. ALL REPLACEMENT PARTS, WHETHER NEW OR REMANUFACTURED, ASSUME AS THEIR WARRANTY PERIOD ONLY THE REMAINING TIME PERIOD OF THIS WARRANTY.

THE MANUFACTURER WILL NOT BE RESPONSIBLE FOR:

1. Normal maintenance as outlined in the installation and servicing instructions or owner's manual, including filter cleaning and/or replacement and lubrication.
2. Damage or repairs required as a consequence of faulty installation, misapplication, abuse, improper servicing, unauthorized alteration or improper operation.
3. Failure to start due to voltage conditions, blown fuses, open circuit breakers or other damages due to the inadequacy or interruption of electrical service.
4. Damage as a result of floods, winds, fires, lightning, accidents, corrosive environments or other conditions beyond the control of the Manufacturer.
5. Parts not supplied or designated by the Manufacturer, or damages resulting from their use.
6. Manufacturer products installed outside the continental U.S.A., Alaska, Hawaii, and Canada.
7. Electricity or fuel costs or increases in electricity or fuel costs for any reason whatsoever including additional or unusual use of supplemental electric heat.
8. ANY SPECIAL INDIRECT OR CONSEQUENTIAL PROPERTY OR COMMERCIAL DAMAGE OF ANY NATURE WHATSOEVER. Some states do not allow the exclusion of incidental or consequential damages, so the above may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

ColorDisplay Series Thermostat Controllers

Power Requirements		20 - 30 VAC 50/60 Hz, 4.8 VA @ 24V nominal.
Output Rating		W1, W2, W3 = 0.2A max, 0.01A min, 3A inrush, 20 - 30 VAC Y1, Y2, G = 0.4A max, 0.01A min, 3A inrush, 20 - 30 VAC
Local Temperature Sensor Type		Thermistor, NTC 10K @ 25C
Remote Temperature Sensor Type		Thermistor, NTC 10K @ 25C
Wire Size		16 AWG (100 ft max) to 24 AWG (36 ft max)
Temperature Adjustment Range		35 to 99 deg F (2 to 36 degC)
Accuracy		35 to 65 deg F +/- 3 degF, greater than 65 to less than 80 degF +/- 2 degF, 80 to 99 degF +/- 3 degF, greater than 99 to 104 degF +/- 5 degF
Humidity		+/- 10% RH from 30-70% RH, 50-90F
Deadband		Adjustable 1 to 6 deg first stage, 0 - 10 deg 2nd & 3rd stages
Ambient Conditions	Operating	35 to 104 degF (2 to 40 degC), 5 - 95% RH non-condensing, 86 degF max dew point
	Storage	-22 to 122 degF (-30 to 50 degC), 5-95% RH non-condensing, 86 degF max dew point
Compliance		UL/cUL listed, file E107041, NEC Class 2
Dimensions		4.0" H x 5.2" W x 1.1"D
Shipping Weight		0.34 kg

North American Emissions Compliance

United States

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when this equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case the users will be required to correct the interference at their own expense.

Canada

This Class (B) digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment Regulations.
Cet appareil numérique de la Classe (B) respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.



Printed on recycled paper.
12012271 Rev. 3 09/17

